

PLEASE !! READ THROUGH ALL OF THE INSTRUCTION STEPS BEFORE STARTING. THE PARTS ARE DESIGNED TO BE PRECISE FITTING AND SOME ASSEMBLIES BUILD ON PREVIOUS STEPS.

SOME MODELERS PREFER TO BUILD THE STRUCTURE COMPLETELY BEFORE PAINTING. ALL PARTS MAY BE PAINTED BEFORE ASSEMBLY WHILE THEY ARE STILL ON THEIR SPRUES. ONCE THE WALL PARTS HAVE BEEN PAINTED, THEY CAN BE CUT FROM THE SPRUE. INSTALLING THE WINDOWS AND DOORS AND SOME OF THE TRIM MAY BE ADVANTAGEOUS AT THIS POINT. COMPLETED WALL SECTIONS CAN THEN BE ASSEMBLED PER THE INSTRUCTIONS.

1. THE FIBER TASK BOARD (PART 'E') SHOULD BE PRIMED WITH AN ENAMEL (OIL) BASED PRIMER BEFORE APPLYING ACRYLIC PAINT. IF THE ACRYLIC PAINT HAS TOO MUCH WATER SOLVENT IN IT, THE BOARD MAY SWELL. IF IT DOES - **ALLOW IT TO DRY THOROUGHLY BEFORE PROCEEDING.**
2. BEFORE YOU BEGIN CONSTRUCTION, TAKE THE TIME TO BECOME FAMILIAR WITH THE PARTS AND INSTRUCTIONS. THE PARTS ARE NUMBERED TO MAKE IT EASIER TO FIND THEM ON THE SPRUES.
3. FRET "C" HAS A PEEL-AND-STICK BACKING TO HELP WITH CONSTRUCTION. LIGHTLY PLACE THESE PARTS AND, WHEN IN THEIR CORRECT POSITION, PRESS TO FIT THEM INTO PLACE. IT IS USUALLY EASIER TO PAINT THESE PARTS BEFORE FIXING IN PLACE.
4. WE RECOMMEND VALLEJO BRAND ACRYLIC PAINTS FOR THIS KIT.

AS WITH ALL OF OUR KITS WE HOPE YOU ENJOY BUILDING AND FINISHING THIS MODEL. PLEASE LET US KNOW OF ANY SUGGESTIONS OR IDEAS YOU MIGHT HAVE TO IMPROVE OUR KITS.

PLEASE VISIT OUR WEBSITE AT WWW.SHOWCASEMINIATURES.NET TO ENSURE THAT YOU HAVE THE LATEST VERSION OF THE ASSEMBLY INSTRUCTIONS.

PARTS

The assembly guide includes the following components and steps:

- Parts List:**
 - A:** Wall panels (1-9)
 - B:** Window and door panels (1-4)
 - C:** Fret with PSA backing (1-4)
 - D:** Trim pieces (1-2)
 - E:** Fiber task board (1-2)
- Assembly Steps:**
 1. Assemble the sink, oven, and cabinet on the floor graphic (E).
 2. Suggest placement of LED and drill for LED wires.
 3. Attach wall panels (A1-A5) and window/door panels (B1-B3).
 4. Attach trim pieces (A2, A3, A4).
 5. Attach the fiber task board (E) and PSA fret (C).
 6. Attach the paper canopy (folded) and floor graphic.
 7. Attach the main graphics and AC unit.
 8. Attach the rear door canopy and oven vent.
- Additional Components:**
 - FRONT CANOPY, REAR DOOR CANOPY, FLOOR GRAPHIC, GRAPHIC SHEET, SIGN GRAPHICS
 - OVEN, SINK, CABINET, FLOOR GRAPHIC
 - PAPER CANOPY (FOLDED) SEE ABOVE
 - GRAPHIC, AC UNIT (IN PLACE), REAR DOOR CANOPY (ON BACK), OVEN VENT
 - BAR STOOLS