



DECALS:

WATERSLIDE DECALS ARE INCLUDED FOR THIS KIT BUT ARE NOT PRE-CUT AND MUST BE CUT AS CLOSE TO THE EDGE OF THE GRAPHIC AS POSSIBLE.

WINDSHIELD:

A VACUUM FORMED PART IS INCLUDED TO CREATE A WINDSHIELD FOR THE TRUCK CAB. FIT THE CLEAR CANOPY PART OVER THE METAL MANDREL AND, USING A SHARP HOBBY KNIFE, CUT AROUND THE EDGES OF THE WINDSHIELD. USE A CANOPY GLUE TO ATTACH TO THE CAB LAST AFTER ASSEMBLY AND PAINTING IS COMPLETE.