



## ASSEMBLY

- 1) CAREFULLY CUT INDIVIDUAL PARTS OFF THE SPRUE AS YOU NEED THEM USING A SHARP, HEAVY BLADED KNIFE ON A HARD SURFACE.
- 2) THE PARTS FIT TOGETHER USING TAB AND SLOT JOINTS AND CAN BE HELD TOGETHER IN PLACE WHILE APPLYING THE GLUE.
- 3) WE RECOMMEND USING CA TYPE (SUPER GLUE) TO ASSEMBLE THE BRIDGE. PLACE A SMALL AMOUNT OF SUPER GLUE ON A PIECE OF PLASTIC AND, USING A THIN WIRE, PUT JUST A TINY DROP ON THE TAB AND SLOT JOINT.
- 4) ONCE THE ASSEMBLY IS HELD IN PLACE AT THE TAB AND SLOT JOINTS, MORE GLUE CAN BE APPLIED ALONG THE SEAMS.
- 5) SOME PARTS CAN BE HELD IN PLACE USING CANOPY GLUE AND THEN PERMANENTLY GLUED WITH SUPER GLUE.



