



### WINDSHIELD:

A VACUUM FORMED PART IS INCLUDED TO CREATE A WINDSHIELD FOR THE TRUCK CAB. FIT THE CLEAR CANOPY PART OVER THE INCLUDED METAL MANDREL AND, USING A SHARP HOBBY KNIFE, CUT AROUND THE EDGES OF THE WINDSHIELD. USE A CANOPY GLUE TO ATTACH TO THE OUTSIDE OF THE CAB LAST AFTER ASSEMBLY AND PAINTING IS COMPLETE.

This kit contains resin, pewter, brass and Stainless Steel parts. For best results, clean all metal parts in Rubbing Alcohol before assembly. Resin Parts can be cleaned with warm, soapy water. Let all parts dry thoroughly before painting. We recommend priming all parts with a lacquer based primer (such as Tamiya). For more tips and information, please check our website:

[www.showcaseminatures.net](http://www.showcaseminatures.net)