

# A Decal for the Wigwag Banjo Is Included

The decal is as thin as a layer of paint and delicate. Apply as with a normal decal but it will need to be sealed once it has completely dried.

## Painting the Wigwag Banjo Craftsman Method

Paint the swinging target white then, with a small brush, paint the outer ring and cross target black.



Paint center of target  
RED. Once paint has dried,  
fill cavity with CLEAR varnish.



## Quick and Easy Method

File off the center of the wig wag disk. Using the printed targets, cut around the outside perimeter with small crochet scissors or use a hand held 1/4 inch hole punch (available at stationary stores). Use Super Glue (CA adhesive) to attach the targets, properly aligned, to the front and back of the wig wag disk.