

PLEASE !! READ THROUGH ALL OF THE INSTRUCTION STEPS BEFORE STARTING. THE PARTS ARE DESIGNED TO BE PRECISE FITTING AND SOME ASSEMBLIES BUILD ON PREVIOUS STEPS.

THIS KIT HAS BEEN DESIGNED TO MINIMIZE SOME OF THE PAINTING REQUIREMENTS NEEDED FOR MOST CRAFTSMAN KITS. WE RECOMMEND THAT YOU BUILD THE SUB-ASSEMBLIES AS SHOWN IN THE ILLUSTRATED STEPS. SOME MODELERS PREFER TO BUILD THE STRUCTURE COMPLETELY BEFORE PAINTING. ALL PARTS MAY BE PAINTED BEFORE ASSEMBLY WHILE THEY ARE STILL ON THEIR SPRUES.

1. BEFORE YOU BEGIN CONSTRUCTION, TAKE THE TIME TO BECOME FAMILIAR WITH THE PARTS AND INSTRUCTIONS. THE PARTS ARE NUMBERED TO MAKE IT EASIER TO FIND THEM ON THE SPRUES. **IN GENERAL, MOST PARTS CAN BE ASSEMBLED AND WILL HOLD THEMSELVES IN PLACE ALLOWING YOU TO APPLY GLUE TO THE TAB AND SLOT AREAS. WE RECOMMEND CARPENTERS WOOD GLUE FOR ASSEMBLY.**


2. THE WINDOWS AND DOORS HAVE A DOUBLE STICK ADHESIVE BACKING TO ALLOW THEM TO BE APPLIED TO THE GLAZING. WE RECOMMEND THAT YOU PAINT THE WINDOWS AND DOORS WHILE THEY ARE STILL ATTACHED TO THE SPRUE. SPRAY PAINT WORKS BEST FOR THIS.

3. WE RECOMMEND AN ENAMEL OR LAQUER BASED PRIMER LIKE TAMIYA SURFACE PRIMER TO SEAL AND PROTECT THE PARTS. WE ALSO RECOMMEND VALLEJO BRAND ACRYLIC PAINTS FOR THIS KIT.





4. **SOME OF THE PARTS (MOST OF THE WALLS) HAVE BEEN LAMINATED WITH A PRINTED TEXTURE TO MAKE FINISHING THIS MODEL EASIER. THE TEXTURE IS PRINTED IN WATERBASE INK SO, WHILE THE PAPER AND PRINT IS STABLE FOR GLUEING AND PAINTING, CARE SHOULD BE TAKEN TO MINIMIZE THE USE OF WATER BASED PAINTS, STAINS AND WASHES THAT MIGHT DAMAGE THE PRINT.**

AS WITH ALL OF OUR KITS WE HOPE YOU ENJOY BUILDING AND FINISHING THIS MODEL. PLEASE LET US KNOW OF ANY SUGGESTIONS OR IDEAS YOU MIGHT HAVE TO IMPROVE OUR KITS.




PLEASE VISIT OUR WEBSITE AT WWW.SHOWCASEMINIATURES.NET TO ENSURE THAT YOU HAVE THE LATEST VERSION OF THE ASSEMBLY INSTRUCTIONS.







PARTS









CAST PEWTER PARTS





PARTS LABELED IN BLUE ARE OPTIONAL




STEP 11

APPLY GLUE EVENLY OVER SUB ROOF PANELS.


GLUE ROOF (H1) IN PLACE BEFORE ADDING BASE (E6)

FOLD H1 ALONG LINES SHOWN.



STEP 12




FOLD H3 ALONG LINES SHOWN.





STEP 13

STEP 14



STEP 15




STEP 16



USE SMALL AMOUNT OF FILLER IN JOINTS



USE SMALL AMOUNT OF FILLER IN JOINTS



ELEVATIONS